

## DA20-C1 BOLDFACE

ABORT  <b>THROTTLE — IDLE</b> <b>BRAKES — AS REQUIRED</b> <b>FLAPS — CRUISE</b>
ENGINE MALFUNCTION — SUFFICIENT RUNWAY REMAINING TO LAND  <b>AIRSPEED — 60 KIAS</b> <b>FLAPS — LDG</b>
FUEL PRESSURE LOSS  <b>FUEL PUMP — ON</b>
ENGINE FIRE IN FLIGHT  <b>FUEL SHUTOFF VALVE — OFF</b> <b>CABIN HEAT — OFF</b>
ENGINE FIRE ON THE GROUND  <b>FUEL SHUTOFF VALVE — OFF</b> <b>CABIN HEAT — OFF</b>
ELECTRICAL FIRE ON THE GROUND  <b>GEN/BAT MASTER SWITCH — OFF</b>
ELECTRICAL FIRE IN FLIGHT  <b>GEN/BAT MASTER SWITCH — OFF</b> <b>AIR VENTS AND WINDOWS — OPEN</b>
CABIN FIRE IN FLIGHT  <b>GEN/BAT MASTER SWITCH — OFF</b> <b>AIR VENTS AND WINDOWS — OPEN</b> <b>CABIN HEAT — OFF</b>

10 FEB 2015

## DA20-C1 BOLDFACE

ABORT  <b>THROTTLE — IDLE</b> <b>BRAKES — AS REQUIRED</b> <b>FLAPS — CRUISE</b>
ENGINE MALFUNCTION — SUFFICIENT RUNWAY REMAINING TO LAND  <b>AIRSPEED — 60 KIAS</b> <b>FLAPS — LDG</b>
FUEL PRESSURE LOSS  <b>FUEL PUMP — ON</b>
ENGINE FIRE IN FLIGHT  <b>FUEL SHUTOFF VALVE — OFF</b> <b>CABIN HEAT — OFF</b>
ENGINE FIRE ON THE GROUND  <b>FUEL SHUTOFF VALVE — OFF</b> <b>CABIN HEAT — OFF</b>
ELECTRICAL FIRE ON THE GROUND  <b>GEN/BAT MASTER SWITCH — OFF</b>
ELECTRICAL FIRE IN FLIGHT  <b>GEN/BAT MASTER SWITCH — OFF</b> <b>AIR VENTS AND WINDOWS — OPEN</b>
CABIN FIRE IN FLIGHT  <b>GEN/BAT MASTER SWITCH — OFF</b> <b>AIR VENTS AND WINDOWS — OPEN</b> <b>CABIN HEAT — OFF</b>

10 FEB 2015

# DA20-C1 BOLDFACE

ABORT
ENGINE MALFUNCTION — SUFFICIENT RUNWAY REMAINING TO LAND
FUEL PRESSURE LOSS
ENGINE FIRE IN FLIGHT
ENGINE FIRE ON THE GROUND
ELECTRICAL FIRE ON THE GROUND
ELECTRICAL FIRE IN FLIGHT
CABIN FIRE IN FLIGHT

10 FEB 2015